

Sick Bike Parts.com

INSTALLATION OF THE OPTIONAL MUFFLER ON SBP TUNED EXPANSION CHAMBER

DO NOT FORCE OR HAMMER MUFFLER ON. DO NOT TWIST THE ASSEMBLY BY HOLDING THE MUFFLER.

1) Test fit copper fitting on silencer tip. It will be a tight fit - depending mainly on the chrome plating thickness. It may be necessary to remove burrs or open the copper fitting up a small amount.

2) Install hose clamp over copper fitting and tighten in place:



Optional method: Install muffler per step one, drill a small hole (~ 3/32") through copper fitting and insert cotter pin:

