

Sick Bike Parts.com

Requirements for using this kit.

Please read through this list carefully. If you, or your bike, do not meet these requirements this upgrade kit is not for you.

You must:

1. be an experienced bicycle mechanic
2. be an experienced motored bicycle mechanic
3. have a typical Chinese 2 stroke bicycle engine kit
4. have a standard square-taper 3 piece bottom bracket, conversion kits are available on our site
5. have a chromoly or quick release rear axle, standard steel axles will bend
6. have a typical mountain bike V-frame, but will also work on most "cruiser" style frames
7. have no greater than a 1 3/8" seat tube, **please specify during order process**
8. have more than 1 1/2" clearance from the back of the seat tube to your rear tire
9. have a quality rear derailleur, internal hub shifter or NuVinci hub
10. have a bike with V or Disc Brakes, coaster brakes will not work with the kit

Here is a list of tools that are required to complete the build other than your standard wrenches and screwdrivers.

1. file
2. chain breaker or equivalent
3. crank removal tool
4. knife or tin snips
5. contact cement
6. thread locking compound
7. drill and drill bit assortment