

Sick Bike Parts.com

INSTALLATION OF THE SBP ADJUSTABLE REAR MOUNT KICKSTAND



1) Lay out all the supplied parts like this:



2) When assembling this kickstand consult all the pictures here to give you a feel on how the pieces fit. Always leave the bolts loose until you are nearly complete, this will allow you to properly position the clamping pieces.



3) With bike held firmly in position, loosely install the main kickstand portion and large rear clamshell clamp (pictured above not clamped on frame). Align holes and loosely thread in the two medium length bolts. The kickstand in one easy step is now hanging loosely on the frame near the rear drop out.

4) Next you will be working with the parts you just installed and these parts (and the two short bolts - not shown above):



Install the two short bolts through slot (one at a time) on main kickstand piece into the threaded holes in the upper strut support piece:




Then grab this part:




And slip the tang into the square hole, wrapping around the bike frame and into the upper strut support piece, and thread the longest bolt through the remaining hole in the upper strut support piece into the threaded hole in the piece with the tang.

It should look like this:



5. Now all pieces should be in place. It's time to roughly adjust the height of the kickstand. First begin by slightly snugging up the bolts you just installed - NOT tight, just take most of the wobble out. Then loosen the adjusting screw and slide the kickstand extension to the necessary length to hold the bike in position at a slight leaning angle:



6) When adjusted, tighten all the screws. Retighten after first use.

